



Komponenten / Ersatzteile

Position	Artikel-Nr.	Beschreibung	Position	Artikel-Nr.	Beschreibung
4	415231001104	Steckdose (20A/250V) CONSENT (20A/250V)	54	415231001154	Mutter M8 NUT, FANGE M8
11	415231001111	Voltmeter VOLTMETER ASSY	69	415231001169	Zylinderkopfdichtung GASKET, CYLINDER HEAD
12	415231001013	Sicherung PROTECTOR, CIRCUIT (10A)	70	415231001170	Dichtung sealing
24	415231001031	Luftfiltergehäusedeckel housing cover for air filter	71	415231001171	Abdeckung COVER COMP, HEAD
29	415231001037	Auspuffgehäuse MUFFLER COMP	72	415231001172	Abluftschlauch EXHAUST PIPE
30	415231001038	Gehäuse INSULATOR, MUFFLER PROTECTOR	77	415231001177	Ölwächter SWITCH ASSY, OIL LEVEL
32	415231001041	Auspuffdichtung GASKET, EX, PIPE	84	415231001184	Öleinfüllstutzen CAP ASSY, OIL FILLER
40	415231001046	Kraftstofftank fuel tank	89	415231001189	Öleinfüllstopfen OIL FILLER PLUG

Komponenten / Ersatzteile

Position	Artikel-Nr.	Beschreibung
91	415231001191	Kolbenringe FIRST RING SET, PISTON
92	415231001192	Kolben PISTON
93	415231001193	Kolbenbolzen PIN, PISTON
94	415231001194	Pleuel CONNECTING ROD ASSY
95	415231001195	Sicherungsring CLIP, PISTON PIN, 18MM
104	415231001204	Feder SPRING, VALVE
105	415231001205	Klemmring RETAINER, IN?VALVE SPRING
106	415231001206	Klemmring RETAINER, IN?VALVE SPRING
127	415231001048	Vergaser carburetor, assy
131	415231001231	Dichtung PACKING, CARBURETOR
135	415231001002	Lüfterrad FAN, COOLING
139	415231001006	Schwungrad FLYWHEEL COMP
901	415231001001	Startglocke pulley starter complet
902	415231001004	Zündspule m. Zündkerzenstecker ignition plug
903	415231001047	Tankdeckel CAP COMP, FUEL FILLER
0	415231001012	Starterzugknopf starter knob
0	415231001015	Starterseil starter rope
0	415231001053	Schlüssel On/Off key on/off
0	415231001054	Werkzeug Satz tool set
0	415231001055	Ersatzkohlen (Regler) carbon brush (regulator) (pair)